



1. Apply a small bead of **100% Silicone** (non-waterbased) around the underside of strainer flange (1).
2. Assemble nut (4), washer (3) and gasket (2) (taper side up) to tailpiece (5). Thread tailpiece (5) into strainer flange (1) and tighten nut (4).

*Note: Rubber washer is only used for glass sinks.

Remove all excess silicone around the drain after the drain has been installed