

General Installation Notes:

CAUTION:

Risk of personal injury. Large sinks can be extremely heavy. Obtain sufficient help to carefully lift or move.

- All Native Trails products should be installed by a licensed contractor, Native Trails will not be responsible for improper sink or countertop installations.
- Observe and comply with all building and plumbing codes.
- As our basins are handcrafted and dimensions are approximate, we recommend using the actual basin for any cutouts.
- Use 100% Silicone (non-water based) for all installations.
- Ensure adequate space behind the basin for faucet and backsplash, including the full range of motion for faucet handles and spouts.
- Make sure a watertight seal exists on all drain connections.
- Do not place basin directly on floor. After unpacking, place basin on protective material such as packing materials.
- Remember to always use non-abrasive cleaners on Native Trails sinks and tubs. Mild soap and water is recommended. Refer to Care and Cleaning Instructions for further information.
- If unsure which instructions pertain to your product call our Customer Service Department at 800.786.0862. You may also view Installation and Care and Cleaning Instructions at nativetrailshome.com.

Apron Front Concierge Sink Installation

1. Use your actual sink as your template. Measure outside dimensions of basin and mark your cabinet accordingly for apron cutout.
2. Cut cabinet on marked line.
3. We recommend Native Trails Sink Undermount Kits (*large or small*). Select the appropriate size and follow the kit instructions. Consult your installer to determine the best option.
4. Place your sink in cabinet opening making sure it's flush with the top of the cabinet and sits level.
5. Measure the inside dimensions of the basin and mark the countertop accordingly. ***To ensure proper accessory use, install Concierge sinks with the angled ledge exposed.***
6. Cut countertop. Apply a bead of silicone around the top edge of the sink and install countertop.
7. Apply silicone to fill any visual gaps between sink and countertop as well as cabinet.
8. Carefully remove any excess silicone.
9. Install the drain according to the drain's installation instructions. Do not over tighten.

Undermount Concierge Sink Installation

1. Use your actual sink as your template. Place it upside down on countertop and mark countertop by tracing edge of basin. Be sure to allow clearance for faucet and other accessories or fixtures.
2. Measure the inside dimensions of the basin and mark the countertop accordingly. ***To ensure proper accessory use, install Concierge sinks with the angled ledge exposed.***
3. Cut countertop on inside line. Temporarily position the basin beneath the cutout to verify proper fit and confirm that the angled ledge is exposed.
4. Apply a bead of silicone around the top edge of the sink. Adhere to underside of countertop.
5. Secure the basin under the countertop using mounting clips (*copper sinks only*) or a Native Trails Undermount Kit (*large or small*). Select the appropriate size and follow the kit instructions. Consult your installer to determine the best option.
6. Carefully remove any excess silicone.
7. Install the drain according to the drain's installation instructions. Do not over tighten.