Installation Instructions

DR130 Dome Drain

General Instructions:

- We strongly recommend this product be installed by a professional installer.
- Disassemble and account for all pieces shown in "Parts Included" section.
- · Drain intended to be used in sink without overflow

Materials Recommended:

100% Silicone (non-water based)

Thread Seal Tape

3. Insert the Drain Body (B) into the sink drain



- hole, ensuring that the silicone or Rubber Washer (C) are in contact with the sink.

 4. From under the sink, in order, slide the Rubber Gasket (D), the Plastic Washer (E), and the Lock Nut (F) up the threaded shaft of the Drain Body (B) and tighten into position against the sink underside. *Do not overtighten.

8. From under the sink, screw the taped end of

the Tailpiece (G) into Drain Body (B) until it

- 5. Check the Stopper (A) for proper push to seal function.
 6. If silicone was used, wipe away any excess silicone around the drain area.
- the Tailpiece (G). we recommend wrapping tape securely around the threads at least 4 times.

7. Apply Thread Seal Tape around the threads of