

INSTALLATION INSTRUCTIONS 1.5" Push to Seal Drain, DR130

- 1 2
- 1. Separate all mounting hardware as shown.
- Either apply 100% Silicone (non-water based) to underside of flange (1) OR place rubber seat washer (2) directly under the flange and then place directly into drain opening of the sink
- 3. From underneath the sink slide the Rubber Gaskets (3,4 & 5), the Retaining Washer (6), and the Lock Nut (7) onto the Threaded Seat (1) and tighten into position.
- 4. Wrap the threads on the Tailpipe (8) with Teflon Tape.
- 5. Screw Tailpipe (8) into the bottom of Threaded Seat (1)

---- SINK -----

- <u>6</u> _____
- 8

Remove all excess silicone around the drain after the drain has been installed