

INSTALLATION INSTRUCTIONS

WALL MOUNT VANITIES

It is strongly recommended that Native Trails wall mount vanities are installed by a licensed contractor.

TOPANGA AND VINTNERS FLOATING VANITIES

1. Determine desired height and location of studs in wall.
2. Attach French Cleat **(B)** to wall using at least two 4.5" screws per stud. (Fastenmaster HeadLOK Heavy-Duty Flathead Fasteners are recommended). Make sure it is level and at proper height to support vanity and that the slanted edge of French Cleat **(B)** will fit evenly with slanted edge of French Cleat **(A)**.
3. Hang vanity on French Cleat **(B)** attached to wall.
4. From underneath vanity, install at least two 4.5" screws per stud through vanity and into French Cleat **(A)** to secure vanity to studs.
5. Install top, sink, and drain according to installation instructions.

