Installation Instructions

DR120 Dome Drain

General Instructions:


- We strongly recommend this product be installed by a professional installer.
- Disassemble and account for all pieces shown in "Parts Included" section.
- · Drain intended to be used in sink without overflow

Materials Recommended:

100% Silicone (non-water based)

Thread Seal Tape

3. Insert the Drain Body (B) into the sink drain





- 1. Clean and remove any loose debris from the drain hole located in the bottom of your sink.

 2. Slide the Rubber Washer (C) onto the Drain Body's (B) threaded shaft until it reaches the underside of the flange or apply a bead of 100% silicone evenly around the underside of the flange of the Drain Body (B). *If installing a glass sink, using the Rubber Washer (C) is recommended.
- hole, ensuring that the silicone or Rubber Washer (C) are in contact with the sink.


 4. From under the sink, in order, slide the Rubber Gasket (D) up onto the Drain Body's (B) threaded shaft until it stops against the sink underside. Place the Plastic Washer (E) into the indented opening at the top of the Flanged Underbody (F).

(F)





7. Apply Thread Seal Tape around the threads of the Tailpiece (G). we recommend wrapping tape securely around the threads at least 4 times.



- **8.**From under the sink, screw the taped end of the Tailpiece (G) into Flanged Underbody (F) until it firmly stops. *Do not overtighten.
- **9.** If silicone was used, allow silicone to dry and check for leaks.
- **10.** Screw Stopper (A) into the top of Drain Body (B) and hand tighten only to secure.

